


QUICK START GUIDE

Step 1 Adjust the Collar



Proper Fit: The collar fit should be snug, yet loose enough to allow one finger to fit between the strap and the dog's neck. Fit is important because a loose collar may cause inconsistent performance. It's okay to trim any excess strap lengths.

Step 2 Power Up



Charge the collar for 14-16 hours. Be sure to cover the charge jack with the gray plug when done.

Step 3 Using the Collar



The collar is activated when the unit is charged. Simply put the collar on your dog and enjoy the peace and quiet. Innotek's Auto-Set feature will do all the work.